

Cleaning, care and use

Storage box

- Suitable for storing dry foods, e.g. onions, garlic and potatoes, at room temperature.
- Clean the storage box by hand with warm water and a mild washing-up liquid before first use and then at regular intervals.
- Do not use caustic or abrasive agents or hard brushes, etc. for cleaning.
- Dry the storage box immediately after washing it to avoid stains caused by natural calcification.
- Place the storage box in a dry location and make sure that the ventilation openings on the storage box are not covered.
- Some varnishes, plastics and types of furniture polish may react adversely to the material of the non-slip feet and soften them. To avoid unwanted marks on furniture, place a non-slip mat underneath the product if necessary.
- The storage box is not suitable for heating up food in the oven, on the stove or in the microwave!

Wooden lid

- Do not use the wooden lid as a chopping board.
- Clean the wooden lid quickly by hand with a little warm water and, if necessary, a little mild washing up liquid. The wooden lid must not be left in the dishwasher for an extended period of time or cleaned under running water. Leave it upright to dry thoroughly after cleaning. The wooden lid is not dishwasher-safe.
- To ensure you can continue using this product for a long time, we recommend oiling the wooden lid at regular intervals. Proceed as follows:
 1. Clean the wooden lid as described, then leave it upright to dry thoroughly.
 2. Apply a few drops of cooking oil (not linseed oil!) to the wood with a brush or lint-free cloth. Wipe off excess oil with a cloth.
 3. Allow the oil to absorb into the wood before using the wooden lid again.

Product number: 767 342

Made exclusively for:

Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany