



## en Instructions for assembly and use

## Attaching the microfibre pad to the window squeegee



## Attaching the window squeegee to the telescopic handle (of the floor mop - product no. 718 426)



## Important information

- Be careful when removing the window squeegee from the telescopic handle so that you do not pinch your fingers on the snap lock.
- If necessary, wipe the telescopic handle with a damp, lint-free cloth.
- The microfibre pad is machine washable.  
Do not use fabric softener. Follow the care instructions on the sewn-in label.
- If you wish to dispose of the product, do so in accordance with current regulations.  
Dispose of the packaging separately.