

Equipment and technical information

MEDION® E49363 (MD 88363) WEBCAM WITH STUDIO LIGHT

MEDION®



This information sheet is part of the user manual. Read the user manual carefully and in full. This information sheet does not replace the user manual. Read the chapter entitled "Safety" in the user manual before you start and follow the detailed instructions for setup and connection.

Information about this user manual



Thank you for choosing our product. We hope you enjoy using this device.

Please read the safety instructions and the user manual carefully before using the device for the first time. Note the warnings on the device and in the user manual.

Always keep the user manual close to hand. If you sell the device or give it away, please ensure that you also pass on this user manual. It is an essential component of the product.

Explanation of symbols

If a block of text is marked with one of the warning symbols listed below, the hazard described in that text must be avoided to prevent the potential consequences described there from occurring.



DANGER!

Warning: risk of fatal injury!



WARNING!

Warning: risk of possible fatal injury and/or serious irreversible injuries!



CAUTION!

Warning: risk of minor and/or moderate injuries!



More detailed information about using the device!

Proper use

Your device can be used in the following ways:

This product is intended for recording videos and taking photographs on a computer/notebook with USB ports.

- The device is only intended for private use and not for industrial/commercial use.
- Please note that we shall not be liable in cases of improper use:
- Do not modify the device without our consent and do not use any auxiliary equipment that we have not approved or supplied.
- Only use replacement parts or accessories that we have supplied or approved.
- Comply with all the information in this user manual, especially the safety instructions. Any other use is considered improper and can cause personal injury or property damage.
- Do not use the device in potentially explosive atmospheres. This includes petrol stations, fuel storage areas and areas where solvents are processed. This device must also not be used in areas with particle-laden air (for example, flour or wood dust).
- Do not expose the device to extreme conditions. Avoid:
 - high humidity or wet conditions
 - extremely high or low temperatures

- direct sunlight
- naked flames.

Safety instructions

Operating safety



WARNING!

Risk of injury!

Risk of injury to persons with limited physical, sensory or mental abilities (for example, partially disabled people or older people with limited physical or mental abilities) or to those without experience and knowledge (such as older children).

- ▶ This device can be used by children over the age of 8 and by persons with reduced physical, sensory or mental abilities or by those without experience and/or knowledge, if they are supervised or have been instructed in the safe use of the device and have understood the dangers that result from it.
- ▶ Children must not be allowed to play with the device.
- ▶ Cleaning and user maintenance must not be carried out by children.
- ▶ Children younger than 8 should be kept away from the device and the connection cable.
- ▶ Keep all packaging materials used (bags, pieces of polystyrene etc.) out of reach of children.
- ▶ Do not allow children to play with the packaging material.



There is no right of recourse for lost data or for consequential damage caused by data loss.

This product has been designed for use with a PC.

- ▶ Follow the safety instructions for the computer to which you connect the device.

Installation location

- ▶ Set up and operate the device on a stable, level and vibration-free surface.
- ▶ Keep the device away from moisture, water droplets and spray, and avoid dust, heat and direct sunlight.

Package contents

Check whether all the items in the delivery are present. Contact us within 14 days after purchase if any items are missing. Always specify the serial number when making enquiries.

The following components are supplied with your webcam:

- Webcam
- Documentation



DANGER!

Risk of choking and suffocation!

Packaging film can be swallowed or used improperly, creating a risk of choking and suffocation.

- ▶ Keep packaging material such as plastic film or plastic bags away from children.



MEDION®

A detailed line drawing of a hand-held ultrasonic scaler. The device consists of a control unit at the bottom and a handpiece at the top. The handpiece has a circular face with a scalloped outer edge. Inside this face are concentric circles and a central control knob. Five numbered labels point to specific parts: 1 points to the outer scalloped edge, 2 points to the inner concentric circles, 3 points to the central control knob, 4 points to a small circular feature below the concentric circles, and 5 points to the control unit at the base.

-

- 

Webcam	
Connections	1 x USB cable, approx. 1.5 m
USB TYPE	TYPE -A
Input voltage	5 V 600 mA
Dimensions (L x D x H)	Approx. 92 x 57.5 x 46.3 mm
Weight	Approx. 103 g
Resolution	Max. 2592 x 1944



Opening times	Hotline number UK
Mon – Fri: 08.00 – 20.00 Sat – Sun: 10.00 – 16.00	☎ 0333 3213106
Service address	
MEDION Electronics Ltd. 120 Faraday Park, Faraday Road, Dorcan Swindon SN3 5JF, Wiltshire United Kingdom	



08.06.2022 12:33:55