


Butter dish



Important information

- The product is suitable for storing and serving butter, not for cooking or baking. Only use it for its intended purpose.
- Do not place the butter directly onto the bamboo base; instead, always place it onto the silicone tray designed for this purpose.
- Clean the lid and removable silicone tray with hot water and a mild washing-up liquid before using them for the first time and after every further use. Both parts are also dishwasher-safe.
- The bamboo base is not dishwasher-safe. Wash it under warm, running water only, using a few drops of a mild washing-up liquid if necessary. Then wipe the base dry and leave it to air dry in an upright position.