





Lupe


de Bedienungsanleitung




Batterien einlegen



Aufstellen und Position des Lupenkopfes verstellen



Beleuchtung ein- und ausschalten



Sicherheitshinweise

Lesen Sie aufmerksam die Sicherheitshinweise und benutzen Sie den Artikel nur wie in dieser Anleitung beschrieben, damit es nicht versehentlich zu Verletzungen oder Schäden kommt. Bewahren Sie diese Anleitung zum späteren Nachlesen auf. Bei Weitergabe des Artikels ist auch diese Anleitung mitzugeben.

Verwendungszweck

Der Artikel ist zum Gebrauch in trockenen Innenräumen geeignet. Der Artikel ist für den Privatgebrauch konzipiert und für gewerbliche Zwecke ungeeignet.

GEFAHR für Kinder

- Der Artikel ist kein Spielzeug. Halten Sie Kinder von dem Artikel fern.
- Halten Sie Kinder von Verpackungsmaterial fern. Es besteht u.a. Erstickungsgefahr!
- Batterien können bei Verschlucken lebensgefährlich sein. Wurde eine Batterie verschluckt, kann dies innerhalb von 2 Stunden zu schweren inneren Verätzungen und zum Tode führen. Bewahren Sie deshalb sowohl neue als auch verbrauchte Batterien und den Artikel für Kinder unerschwingbar auf. Wenn Sie vermuten, eine Batterie könnte verschluckt oder anderweitig in den Körper gelangt sein, nehmen Sie sofort medizinische Hilfe in Anspruch.

WARNUNG vor Augenschäden/Brand

- Sehen Sie niemals mit der Lupe in die Sonne! Erblindungsgefahr!
-  Feuegefährlich! Lupe nicht direkter Sonneneinstrahlung aussetzen. Die Lupe kann die Energie der Sonnenstrahlen bündeln und dadurch brennbares Material so stark erhitzen, dass es sich entzündet.
- Sollte eine Batterie ausgelaufen sein, vermeiden Sie Kontakt mit Haut, Augen und Schleimhäuten. Spülen Sie ggf. die betroffenen Stellen mit Wasser und suchen Sie umgehend einen Arzt auf.
- Batterien dürfen nicht geladen, auseinandergenommen, in Feuer geworfen oder kurzgeschlossen werden.

VORSICHT vor Verletzungen und Sachschäden

- Das Lupenglas ist zerbrechlich. Es besteht Bruch- und damit Verletzungsgefahr!
- Schützen Sie Batterien vor übermäßiger Wärme. Nehmen Sie die Batterien aus dem Artikel heraus, wenn diese erschöpft sind oder Sie den Artikel länger nicht benutzen. So vermeiden Sie Schäden, die durch Auslaufen entstehen können.
- Ersetzen Sie immer alle Batterien. Benutzen Sie keine verschiedenen Batterie-Typen, -Marken oder Batterien mit unterschiedlicher Kapazität.
- Achten Sie beim Einsetzen der Batterien auf die korrekte Polarität (+/-).
- Aufgrund ihrer extrem langen Lebensdauer ist ein Wechseln der Leuchtdioden nicht nötig. Sie können und dürfen nicht gewechselt werden. Die Leuchtdioden sind fest in der Lupe montiert.

- Verwenden Sie zum Reinigen keine scharfen Chemikalien, aggressive oder scheuernde Reinigungsmittel.

Reinigen

- ▷ Wischen Sie den Artikel bei Bedarf mit einem leicht angefeuchteten Tuch ab.

Technische Daten

Modell: 366 815 / 373 360

Batterien: 2x LR06(AA)/1,5V

Umgebungstemperatur: +10 bis +40 °C

Made exclusively for:

Tchibo GmbH, Überseering 18,
22297 Hamburg, Germany
www.tchibo.de

Im Zuge von Produktverbesserungen behalten wir uns technische und optische Veränderungen am Artikel vor.



Entsorgen

Der Artikel, seine Verpackung und die mitgelieferten Batterien wurden aus wertvollen Materialien hergestellt, die wiederverwertet werden können. Dies verringert den Abfall und schont die Umwelt.

Entsorgen Sie die **Verpackung** sortenrein. Nutzen Sie dafür die örtlichen Möglichkeiten zum Sammeln von Papier, Pappe und Leichtverpackungen.



Geräte, die mit diesem Symbol gekennzeichnet sind, dürfen nicht mit dem Hausmüll entsorgt werden!

Sie sind gesetzlich dazu verpflichtet, Altgeräte getrennt vom Hausmüll zu entsorgen. Informationen zu Sammelstellen, die Altgeräte kostenlos entgegennehmen, erhalten Sie bei Ihrer Gemeinde- oder Stadtverwaltung.

Wir sind Mitglied des Rücknahmesystems take-e-back. Weitere Informationen dazu finden Sie unter www.tchibo.de/entsorgung.



Batterien und Akkus gehören nicht in den Hausmüll!

Sie sind gesetzlich dazu verpflichtet, leere Batterien und Akkus bei einer Sammelstelle Ihrer Gemeinde- oder Stadtverwaltung oder beim batterievertreibenden Fachhandel abzugeben.




www.tchibo.de/anleitungen

Artikelnummer :

366 815




Magnifying glass




en Instructions for use


Inserting batteries



Setting up and adjusting the position of the glass



Switching the lighting on and off



Safety warnings

Read the safety warnings carefully and only use the product as described in these instructions to avoid accidental injury or damage.

Keep this manual for future reference. If you pass this product on to another person, remember to give them these instructions.

Intended use

The product is suitable for indoor use. It is designed for private use and is not suitable for commercial purposes.

DANGER to children

- The product is not a toy. Keep the product out of the reach of children.
- Keep the packaging material out of the reach of children. There is a risk of suffocation!
- Swallowing batteries can be fatal. If a battery has been swallowed, this can lead to severe internal chemical burns and even death within 2 hours. Therefore, keep both new and old batteries and the product out of the reach of children. If you think that a battery has been swallowed or has got into the body in any other way, seek medical advice immediately.

WARNING - risk of damage to eyes / fire

- Never look at the sun through the magnifying glass. There is otherwise a risk of losing your sight!
-  Risk of fire! Never leave the magnifying glass exposed to direct sunlight. The magnifying glass concentrates the energy from the sun-rays, which can heat flammable material up so much that it catches fire.
- If a battery leaks, avoid contact with skin, eyes and mucous membranes. If necessary, rinse the affected areas with water and consult a doctor immediately.
- Batteries must not be charged, taken apart, thrown into fire or short-circuited.

CAUTION - risk of injury and material damage

- The magnifying glass is fragile. There is a risk that the glass could break, resulting in injury!
- Protect the batteries from excessive heat. Remove the batteries from the product when they are flat or if you do not intend to use the product for any length of time. This will avoid damage that may be caused by leakage.
- Always replace all batteries at the same time. Do not use different types or brands of batteries or batteries with different capacities.
- When inserting batteries ensure that the polarity (+/-) is correct.
- Due to the long service life of the light-emitting diodes (LEDs) it is not necessary to replace them. They cannot and must not be replaced. The light-emitting diodes are securely mounted in the magnifying glass.
- Do not use any caustic, aggressive or abrasive products for cleaning.

Cleaning

- ▷ If necessary, wipe off the product with a slightly dampened cloth.

Technical specifications

Model: 366 815 / 373 360

Batteries: 2x LR06(AA)/1.5V

Ambient temperature: +10 to +40°C

Made exclusively for:
Tchibo GmbH, Überseering 18,
22297 Hamburg Germany

In the course of product improvement, we reserve the right to make technical and optical modifications to the product.



Disposal

This product, its packaging and the supplied batteries have been manufactured from valuable materials that can be recycled. Recycling reduces the amount of refuse and helps to preserve the environment.

Dispose of the **packaging** at a recycling point that sorts materials by type.

Make use of the local facilities provided for collecting paper, cardboard and lightweight packaging.



Devices marked with this symbol must not be disposed of along with normal household refuse!

You are legally bound to dispose of old devices separately from household waste. Information about collection points where old devices can be disposed of free of charge is available from your local authorities.



Standard batteries and rechargeable batteries must not be disposed of along with household refuse!

You are legally bound to dispose of flat batteries and rechargeable batteries at a local authority collection point or to return them to a battery retailer.



www.tchibo.de/instructions

(Please enter the product number in the box labelled "Bedienungsanleitungssuche" and click on "Suchen".)

Product number:

366 815