



## en Instructions for assembly and use

## Attaching the microfibre pad to the mop head



## Attaching the mop head to the telescopic handle



## Important information

- Be careful when removing the mop head from the telescopic handle so that you do not pinch your fingers in the snap lock.
- If necessary, wipe the telescopic handle with a damp, lint-free cloth.
- The microfibre pad is machine washable.  
Do not use fabric softener. Follow the care instructions on the sewn-in label.
- If you wish to dispose of the product, do so in accordance with current regulations.  
Dispose of the packaging separately.