

ASSEMBLY INSTRUCTION

DE - MONTAGEANWEISUNG

FR - INSTRUCTIONS DE MONTAGE

DK - MONTAGEVEJLEDNING

CZ - NÁVOD K MONTÁŽI

ES - INSTRUCCIONES DE MONTAJE

FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU

SE - MONTERINGSANVISNING

SI - NAVODILA ZA MONTAŽO

TR - MONTAJ TALIMATI

NO - MONTASJEANVISNING

IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ

NL - MONTAGE INSTRUCTIE


PT - INSTRUÇÕES DE MONTAGEM

PL - INSTRUKCJA MONTAŻU


HU - SZERELÉSI UTASÍTÁS



15 min



①




x 4

HW-ST-02-046
(8 x 20)


Ⓐ

x 1

SU-SC-MA-0308



②




x 6

HW-ST-02-052
(8 x 35)

Ⓑ

x 1

SU-SC-LF-0472



③




x 6

HW-ST-07-044
(8.5x18x1)


Ⓒ

x 1

SU-SC-LF-0473



④





x 1

HW-ST-18-001
(4 x 98)

Ⓓ

x 2

SU-SC-LF-0471



PREMIUM

