

ASSEMBLY INSTRUCTION

DE - MONTAGEANWEISUNG
FR - INSTRUCTIONS DE MONTAGE
DK - MONTAGEVEJLEDNING
CZ - NÁVOD K MONTÁŽI
ES - INSTRUCCIONES DE MONTAJE
FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU
SE - MONTERINGSANVISNING
SI - NAVODILA ZA MONTAŽO
TR - MONTAJ TALIMATI
NO - MONTASJEANVISNING
IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ
NL - MONTAGE INSTRUCTIE
PT - INSTRUÇÕES DE MONTAGEM
PL - INSTRUKCJA MONTAŻU
HU - SZERELÉSI UTASÍTÁS



20 min



0 cm
1
2
3
4
5
6
7
8
9
10
11
12
13
14


①



x 4

HW-ST-02-046
(8 x 20)

②



x 6

HW-ST-02-052
(8 x 35)


③



x 6

HW-ST-07-044
(8.5x18x1)

④



x 1

HW-ST-18-021
(4 x 82)

⑤

x 1
SU-SC-LF-0472




⑥

x 1
SU-SC-LF-0473



⑦

x 1
SU-SC-MA-0299





⑧

x 1
SU-OT-LF-0134



⑨

x 1
SU-SC-LF-0471



PREMIUM

