

Decorative LED light



Product number: 764 856

Made exclusively for:
Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany



For your safety

Read the safety warnings carefully and only use the product as described in these instructions to avoid accidental injury or damage. Keep these instructions for future reference. If you give this product to another person, remember to also include these instructions.

The product is only suitable for decoration in private homes and not for lighting whole rooms. The product is designed for indoor and outdoor use. It is designed for private use and is not suitable for commercial purposes.

- Keep packaging materials out of the reach of children. They pose several risks, including the risk of suffocation!
- Handle the glass disc carefully so that it does not fall down and break. Keep the product out of the reach of children.
- Swallowing batteries can be fatal. If a battery is swallowed, it can cause severe internal chemical burns and even death within 2 hours. Therefore, keep both new and used batteries and the product out of the reach of children. If you think that a battery has been swallowed or has got into the body in any other way, seek medical advice immediately.
- If a battery has leaked, avoid contact with skin, eyes and mucous membranes. If necessary, rinse the affected areas with water and consult a doctor immediately.
- Batteries must not be taken apart, thrown into fire or short-circuited. In addition, single-use batteries must not be charged.
- Protect batteries / the battery compartment from excessive heat (radiators, direct sunlight). Remove the batteries from the product when they are flat or if you do not intend to use the product for a longer period of time. This will prevent damage caused by leakage.
- Always replace all batteries at the same time. Do not mix old and new batteries, different types or brands of batteries, or batteries with different capacities.
- If necessary, clean the battery and device contacts before inserting batteries. Risk of overheating!
- Ensure that the polarity (+/-) is correct when inserting batteries.
- Do not switch the product on while it is still in the packaging.
- Protect the product from dust, moisture, direct sunlight and extreme temperatures.
- Do not use any caustic, aggressive or abrasive products for cleaning.
- The LEDs are firmly built in and cannot and must not be replaced.

Technical specifications

Model:	764 856
Single-use battery:	2x LR03 (AAA)/1.5 V (Zn/MnO ₂)
Light duration (with 1 set of batteries):	approx. 200 hours
Ambient temperature:	+10 to +40 °C

Information about the supplied batteries

Manufacturer:	CHANGZHOU ANYIDA POWER TECHNOLOGY Co., Ltd., No.1 East Road, Lou Xia Industrial Park, Rulin Town, Jintan District, Changzhou, Jiangsu Province, PR CHINA; www.anyidapower.com
Email:	zoey@anyida-power.com
Model:	Daily-Max LR03 AAA size 1.5 V
Manufacturing date:	2026/04
Made in:	China

Disposal

The product, its packaging and the supplied batteries have been manufactured from valuable materials that can be recycled. Recycling reduces the amount of refuse and preserves the environment.

Dispose of the packaging at a recycling point that sorts materials by type. Make use of the local facilities provided for collecting paper, cardboard and lightweight packaging.



Devices, single-use batteries and rechargeable batteries marked with this symbol must not be disposed of along with household waste!


You are legally obliged to dispose of old devices separately from household waste. Electronic devices contain hazardous substances and, if stored or disposed of improperly, may cause harm to health and the environment. Information about collection points where old devices can be disposed of free of charge is available from your local authorities. Flat single-use and rechargeable batteries must be handed in at a local authority collection point or returned to a battery retailer. Tape off the contacts of lithium single-use/rechargeable batteries prior to disposal.

Use


Inserting/replacing the batteries

▷ If necessary, remove the glass disc from the base.


1. Gently press on the arrow mark on the battery compartment lid and slide the lid off in the direction of the arrow.




2. Fold up the battery compartment lid.





3. Insert the batteries as illustrated inside the battery compartment. Ensure that the polarity (+/-) is correct when doing so.



4. Fold down the battery compartment lid again.



5. Gently press on the arrow mark on the battery compartment lid again and slide the battery compartment lid in the **opposite direction** of the arrow until it stops.



Turning on/off / timer function

- ▷ Slide the switch to **ON** to turn the product on.
- ▷ Slide the switch to **OFF** to turn the product off.
- ▷ Slide the switch to **TIMER** to turn the timer function on.

Timer function: The LEDs are turned on and off as follows:

ON: 6 hours - OFF: 18 hours - ON: 6 hours, and so on.

- ▷ Insert the glass disc into the slot at the top of the base.

