


154673 Multi functional fan camping light



- CAUTION:**
Usage of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
- PRECAUTIONS BEFORE USE**
KEEP THESE INSTRUCTIONS IN MIND:
1. Do not cover or block any ventilation openings. When placing the device on a shelf, leave 5 cm (2") free space around the whole device.
 2. Install in accordance with the supplied user manual.
 3. Keep the device away from heat sources such as radiators, heaters, stoves, candles and other heat-generating products or naked flame.
The device can only be used in moderate climates. Extremely cold or warm environments should be avoided. Working temperature between 0° and 35°C.
 4. Avoid using the device near strong magnetic fields.
 5. Electrostatic discharge can disturb normal usage of this device. If so, simply reset and restart the device following the instruction manual. During file transmission, please handle with care and operate in a static-free environment.
 6. Warning! Never insert an object into the product through the vents or openings. High voltage flows through the product and inserting an object can cause electric shock and/or short circuit internal parts. For the same reason, do not spill water or liquid on the product.
 7. Do not use in wet or moist areas such as bathrooms, steamy kitchens or near swimming pools.
 8. The device shall not be exposed to dripping or splashing and make sure that no objects filled with liquids, such as vases, are placed on or near the apparatus.
 9. Do not use this device when condensation may occur. When the unit is used in a warm wet room with damp, water droplets or condensation may occur inside the unit and the unit may not function properly; let the unit stand in power OFF for 1 or 2 hours before turning on the power: the unit should be dry before getting any power.
 10. Although this device is manufactured with the utmost care and checked several times before leaving the factory, it is still possible that problems may occur, as with all electrical appliances. If you notice smoke, an excessive build-up of heat or any other unexpected phenomena, you should disconnect the plug from the main power socket immediately.
 11. This device must operate on a power source as specified on the specification label. If you are not sure of the type of power supply used in your home, consult your dealer or local power company.
 12. Keep away from animals. Some animals enjoy biting on power cords.
 13. To clean the device, use a soft dry cloth. Do not use solvents or petrol based fluids. To remove severe stains, you may use a damp cloth with dilute detergent.

14. The supplier is not responsible for damage or lost data caused by malfunction, misuse, modification of the device or battery replacement.
15. Do not interrupt the connection when the device is formatting or transferring files. Otherwise, data may be corrupted or lost.
16. If the unit has USB playback function, the USB memory stick should be plugged into the unit directly. Don't use an USB extension cable because it can cause interference resulting in failing of data.
17. The rating label has been marked on the bottom or back panel of the device.
18. This device is not intended for use by people (including children) with physical, sensory or mental disabilities, or a lack of experience and knowledge, unless they're under supervision or have received instructions about the correct use of the device by the person who is responsible for their safety.
19. This product is intended for non professional use only and not for commercial or industrial use.
20. Make sure the unit is adjusted to a stable position. Damage caused by using this product in an unstable position vibrations or shocks or by failure to follow any other warning or precaution contained within this user manual will not be covered by warranty.
21. Never remove the casing of this device.
22. Never place this device on other electrical equipment.
23. Do not allow children access to plastic bags.
24. Only use attachments/accessories specified by the manufacturer.
25. Refer all servicing to qualified service personnel. Servicing is required when the device has been damaged in any way, such as the power supply cord or the plug, when liquid has been spilled or objects have fallen into the device, when the device has been exposed to rain or moisture, does not operate normally, or has been dropped.
26. Long exposure to loud sounds from personal music players may lead to temporary or permanent hearing loss.

Description:



Introduction to the use of camping lights

1. Please fully charge the product before using it for the first time. it takes about 3 to 4 hours to fully charge the product (the actual charging time is subject to the output current of the charger). the battery indicator light flashes when charging, and the battery indicator light stays on when fully charged (for the battery indicator function, please read function analysis 4)
2. Lighting mode switching: press the light source switch to switch in sequence: warm light front light - white light main light strong light - white light main light weak light - white light main light flashing
3. Fan mode switching: press the blower switch to adjust the gears and switch in sequence: soft wind - medium wind - strong wind
4. Battery indicator: when turning on the light and charging, observe that each blue light represents 25% of the battery.
5. Press the switch to turn on the light, and press and hold the switch again to turn off the light. If the last light gear was active longer than 10 sec, simple press will switch off the light.
6. With USB output A function, it can charge mobile phones in an emergency
7. USB charging: universal type-c charging interface, compatible with power banks, notebooks, car charging and other electronic devices.
8. To remove fingerprints on the transparent cover, use a cotton swab dipped in lens cleaner to wipe it gently.

- Model: 759495 2-in-1 LED Fan
- Weight: 341g
- Dimensions: 108*108*98mm
- Input: 5V/1A Max USB C
- Rechargeable battery: Lithium-ion 3.7V 3000mAh (1500mAh*2pcs)
- Watt-hour rating: 11.1 Wh
- Charging time: approx. 3.5 hours
- Operation time with fully charged battery: Approx. 5 hours (using the lowest fan mode)

Manufacturer of rechargeable battery:
Xinxiang Hongli Supply Source Technology Co., Ltd, West section of Xinglong Road, Xinxiang Economic Development Zone, Xinxiang County, Xinxiang City, Henan Province, China
Email: 760172564@qq.com
Manufacturing date : 01/2026

Manufacturer:
Commaxx BV
Wiebachstraat 37
6466 NG Kerkrade
The Netherlands
support@commaxxgoup.com

