




LED make-up mirror

en Instructions for use



Safety warnings \angle !

Read the safety warnings carefully and only use the product as described in these instructions to avoid accidental injury or damage. Keep these instructions for future reference. If you give this product to another person, remember to also include these instructions.

Intended use

The product is designed for private use and is not suitable for commercial purposes.

Danger to children

- Children are not aware of the risks involved in handling electronic devices incorrectly. Therefore, keep the product out of the reach of children.
- Keep packaging materials out of the reach of children.
 They pose several risks, including the risk of suffocation!

Danger due to electricity

- Do not make any modifications to the product. Have repairs to the product carried out only by a specialist workshop.
 Improper repairs can result in considerable danger to the user.
- When charging the battery in the LED mirror, observe the following:
 - The LED mirror must not be charged in the bathroom or in damp rooms.
 - If the LED mirror has got wet, allow it to dry completely before connecting it to the mains power supply with the USB charging cable.

- Do not place any containers filled with liquid, such as vases, etc., on or near the product. The container could tip over and the liquid may affect the safety of the electronics inside. Risk of electric shock.
- Only use suitable charging devices for charging the product.
- Do not use or attempt to repair faulty charging devices.
- Do not connect the LED mirror to the power supply if the mirror itself or the USB charging cable shows visible signs of damage.

Danger of burns/fire

- You cannot and must not attempt to replace or remove the built-in rechargeable battery on your own. If the rechargeable battery is removed or replaced improperly, there is a risk of explosion. Only have the battery replaced with the same or a comparable rechargeable battery.

 If the replaced with a specialist
- If the rechargeable battery is faulty, consult a specialist workshop.
- Do not place any open flames, e.g. burning candles, in the vicinity of the product. Candles and other open flames must always be kept at a distance from the product in order to prevent potential fires from spreading.
- The product contains a lithium-ion rechargeable battery. This
 must not be taken apart, thrown into fire or short-circuited.
- Do not modify, deform, heat up and/or dismantle rechargeable batteries.

Material damage

- Do not immerse the LED mirror or the USB charging cable in water or other liquids.
- Ensure that no moisture is able to enter the USB connection socket.
- Position the USB charging cable in such a way that the LED mirror cannot be accidentally pulled down by the cable while it is charging.
- The USB charging cable must not be kinked or crushed. Keep the USB charging cable away from sharp edges and sources of heat.
- Do not expose the product to any hard impacts and protect it from dust, moisture, direct sunlight exposure and extreme temperatures.
- Do not use abrasive or caustic cleaning agents, or hard brushes, etc., for cleaning.
- The built-in LEDs cannot and must not be replaced.
- Some varnishes, synthetic substances and types of furniture polish may react adversely with the material of the non-slip feet and soften them. To avoid unwanted marks on furniture, place a non-slip mat underneath the product if necessary.

Technical specifications

Model: 717 987

Rechargeable battery: lithium-ion 3.7 V = -1000 mAh (tested as per UN 38.3) Watt-hour rating: 3.7 Wh

(non-replaceable)

Input: 5 V = = = 0.4 A

(the ___ symbol indicates direct

current)

Charging time: approx. 3.5 hours
Operating time: approx. 6 hours

Bulb: LEDs (5500 K: daylight)

Ambient temperature: +10 to +40 °C


Made exclusively for: Tchibo GmbH, Überseering 18,

22297 Hamburg, Germany

Charging the battery

To prevent damage to the rechargeable battery, the product is only half charged upon delivery. Therefore, charge the rechargeable battery fully before using the product for the first time by connecting it to the mains power supply using a mains adapter (not included).

You can switch on the LED lights while the battery is charging, however this will extend the time required to charge the product.



- Insert the end of the USB charging cable into the connection socket on the side of the LED mirror.
- Connect the other end of the USB charging cable to a power socket using a suitable mains adapter (not included).


The charging indicator light lights up red while the device is charging. When empty, the rechargeable battery can be fully charged in approx. 3.5 hours.

Once the battery is fully charged, the charging indicator light turns green.

When the device is charged, remove the mains adapter from the power socket and disconnect the USB charging cable from the LED mirror.

When fully charged, you can use the LED light around the mirror for approx. 6 hours. If the LED light no longer switches on, then the rechargeable battery must be fully recharged.

Switching the LED light on and off



 Gently tap the On/Off switch at the bottom of the mirror's surface to switch on the surrounding LED lights and dim them: bright > dimmer > dim > bright. etc.

The LED lights are always bright when the mirror is switched on.

Touch the On/Off switch and leave your finger in this position to switch off the LED lights again.

Cleaning

- ▶ Wipe the base and frame with a soft, slightly damp cloth as required.
- Carefully clean the surface of the mirror using a soft cloth, slightly dampened with clean water (do not use glass cleaner!) then wipe it dry. Do not allow any moisture to enter the USB connection socket!

Disposal

The product, its packaging and the built-in rechargeable battery have been manufactured from valuable materials that can be recycled. Recycling reduces the amount of refuse and preserves the environment.

Dispose of the **packaging** at a recycling point that sorts materials by type. Make use of the local facilities provided for collecting paper, cardboard and lightweight packaging.

Devices, single-use batteries and rechargeable batteries marked with this symbol must not be disposed of along with household waste!

You are legally obliged to dispose of old devices separately from household waste. Electronic devices contain hazardous substances and, if stored or disposed of improperly, may cause harm to health and the environment. Information about collection points where old devices can be disposed of free of charge is available from your local authorities.

Flat single-use and rechargeable batteries must be handed in at a local authority collection point or returned to a battery retailer. Tape off the contacts of lithium single-use/rechargeable batteries prior to disposal.

Warning! This device contains a rechargeable battery that, for safety reasons, is firmly built into the device and cannot be removed without destroying the casing. Improper disassembly leads to safety hazards. For this reason, take the device intact to a collection point where the device and battery will be disposed of properly.

Product number: 717 987