


Window thermometer


en Instructions for use



Front



Back



Also included (not illustrated):

- 1x mini screwdriver
- 1x single-use battery

Information about the supplied single-use battery

Manufacturer: CHANGZHOU ANYIDA POWER TECHNOLOGY Co., Ltd.

No.1 East Road, Lou Xia Industrial Park, Rulin Town, Jintan District, Changzhou, Jiangsu Province, China

Battery brand: Daily-Max LR03 AAA size 1.5 V

Email: zoey@anyida-power.com **Manufacturing date:** 2025-10 **Made in:** China

Dear Customer

Now you can read the outside temperature and the daily maximum and minimum temperatures conveniently from inside the house – displayed in large digital figures on your window pane. The data is always up to date because it is automatically reset every day.

We hope you enjoy using this product.

Safety warnings



This product is equipped with safety features. Nevertheless, read the safety warnings carefully and only use the product as described in these instructions to avoid accidental injury or damage. Keep these instructions for future reference. If you give this product to another person, remember to also include these instructions.

Intended use

The window thermometer shows you the outside temperature and the maximum and minimum temperatures measured every day. These values are then used by the device to compile weather trends.

The product has been designed for private use and is not suitable for commercial purposes.

Danger to children

- Swallowing batteries can be fatal. If a battery is swallowed, it can cause severe internal chemical burns and even death within 2 hours. Therefore, keep both new and old batteries and the product out of the reach of children. If you think that a battery has been swallowed or has got into the body in any other way, seek medical advice immediately.
- Keep packaging materials and small swallowable parts (screwdrivers) out of the reach of children. They pose several risks, including the risk of suffocation/choking!

Warning – risk of fire/explosion

- Single-use batteries must not be charged, taken apart or crushed, thrown into fire or a hot oven or short-circuited.
- If necessary, clean the battery and device contacts before inserting the battery. Risk of overheating!
- Warning! Batteries can explode if inserted incorrectly. Ensure that the polarity (+/-) is correct when inserting the battery.
- Batteries that are exposed to excessive heat, direct sunlight or extreme temperatures can explode or leak flammable liquids or gases. Protect batteries from excessive heat, direct sunlight and extreme temperatures.
- Batteries that are exposed to extremely low air pressure (e.g. at high altitudes) can explode or flammable liquids or gases can escape.
- Warning! Inserting the wrong type of battery poses a risk of explosion. Only use batteries of the same or equivalent type (see "Technical specifications").

Risk of injury

- If a battery has leaked, avoid contact with skin, eyes and mucous membranes. If necessary, rinse the affected areas with water and consult a doctor immediately.


Material damage

- Protect the device from dust and impacts.
- The device is suitable for outdoor use and complies with protection type IPX4. This means that it is protected against drops and splashes of water, such as rain. Nevertheless, position it in such a way that it is protected from the weather. Do not immerse the product in water.
- Remove the battery from the product when it is flat. This will help prevent damage caused by leakage.
- Do not make any modifications to the product. Have repairs to the product carried out only by a specialist workshop.
- Do not use caustic or solvent-based cleaning products.

Prior to first use

- Do not use a rechargeable battery, as its voltage is too low (only 1.2 V instead of 1.5 V). Among other things, this can affect the accuracy of the measurements.

Opening the battery compartment and inserting the battery



- Unscrew the screws on the battery compartment cover and lift off the battery compartment cover.
- Insert the battery into the battery compartment as illustrated. Ensure correct polarity (+/-). The display briefly shows all the readings.

- The battery must be replaced when the battery symbol appears on the display. When the battery is replaced, the set time is lost.

Selecting the time format

- Briefly press the **SET** button several times to select the display for the time format: 12- or 24-hour display.

Setting the time

- Press and hold the **SET** button for approx. 3 seconds until the hours flash on the display.
- Use the **UP** button to set the hours, then press the **SET** button to save the setting.
- Use the **UP** button to set the minutes, then press the **SET** button to save the setting.

The set time is now shown on the display.


Closing the battery compartment

-
-

Attaching the window thermometer

Important instructions for attaching the window thermometer

- The adhesive pad adheres to all smooth and flat surfaces. The adhesive pad will not adhere to textured surfaces.
 - The adhesive pad is intended for permanent attachment to the outside of the window pane. Avoid attaching the window thermometer to sensitive surfaces if you want to remove it later. Do not expose the thermometer to direct sunlight.
- The surface must be free from dust, grease, silicone and limescale. Clean and degrease the surface with pure alcohol (isopropyl) or methylated spirits if necessary. Bathroom and all-purpose cleaners are not suitable.
 - Gently pre-dry the cleaned area and then leave it to dry completely.



- Remove the protective film from the adhesive pad.

- Position the window thermometer in the desired position and press it firmly for approx. 10 seconds. After approx. 30 minutes, press it again for approx. 10 seconds. Full adhesive strength is achieved after a further 24 hours.

Weather data

Measured daily maximum and minimum temperatures

The device saves the measured maximum and minimum temperatures of the day. The saved values are reset automatically: the maximum value is reset daily around 8 a.m. and the lowest value is reset daily around 8 p.m.

Deleting saved values manually

- Press and hold the **UP** button for approx. 2 seconds to delete the saved values.

Temperature trend

- Rising:
The temperature has risen by more than 1 °C in the last hour.
- Constant:
The temperature has not changed over the last hour.
- Falling:
The temperature has fallen by more than 1 °C in the last hour.

Frost alarm



The adjacent symbol flashes on the display when the temperature is between -1 °C and +2.9 °C.

Temperature

The window thermometer shows temperatures between **-25 °C and +75 °C**.

- If the temperature is **below -25 °C**, it displays **LL.L**.
- If the temperature is **above +75 °C**, it displays **HH.H**.

- If you would like to change the temperature unit from °C to °F, briefly press the **UP** button.

Cleaning

- Wipe off the product with a lint-free, slightly damp cloth as necessary.

Technical specifications

Model:	733 666
Single-use battery:	1x LR03 (AAA) 1.5 V (Zn/MnO ₂)
Temperature measurement range:	-25 °C to +75 °C
IP code:	IPX4
Made exclusively for:	GREND S GmbH, Stahltwiete 23 22761 Hamburg, Germany

Disposal

The product, its packaging and the supplied battery have been manufactured from valuable materials that can be recycled. Recycling reduces the amount of refuse and preserves the environment.

Dispose of the **packaging** at a recycling point that sorts materials by type. Make use of the local facilities provided for collecting paper, cardboard and lightweight packaging.



Devices, single-use batteries and rechargeable batteries marked with this symbol must not be disposed of along with household waste!

You are legally obliged to dispose of old devices separately from household waste. Electronic devices contain hazardous substances and, if stored or disposed of improperly, may cause harm to health and the environment. Information about collection points where old devices can be disposed of free of charge is available from your local authorities. Flat single-use and rechargeable batteries must be handed in at a local authority collection point or returned to a battery retailer. Tape off the contacts of lithium single-use/rechargeable batteries prior to disposal.

Product number: 733 666