

# Room thermometers

en Instructions for use

## For your safety

### Intended use

The room thermometer is designed for measuring the temperature and humidity levels indoors and also for displaying the time.

The product is designed for private use and is not suitable for commercial purposes or public information.

### Danger to children

Swallowing batteries can be fatal.

This product is equipped with coin batteries. Swallowing a coin battery can cause severe internal chemical burns and even death within 2 hours. Keep both new and used batteries out of the reach of children. If the battery compartment does not close properly, discontinue use of the product and keep it out of the reach of children. If you think that a battery has been swallowed or has got into the body in any other way, seek medical advice immediately.

• Keep the packaging materials out of the reach of children.

They pose several risks, including the risk of suffocation!

### Warning - risk of fire/explosion

• Batteries must not be taken apart, thrown into fire or short-circuited. In addition, single-use batteries must not be charged.

• If necessary, clean the battery and device contacts before inserting the battery. Risk of overheating!

• Warning! Lithium batteries can explode if inserted incorrectly. Therefore, ensure correct polarity (+/-) when inserting batteries. Use only batteries of the same or of equivalent type (see the technical specifications).

### Risk of injury

• If a battery has leaked, avoid contact with skin, eyes and mucous membranes. If necessary, rinse the affected areas with water and consult a doctor immediately.

• Protect batteries from excessive heat. Remove the batteries from the product when they are flat or if you do not intend to use the product for a prolonged period. This will prevent damage caused by leakage.

### Material damage

• Protect the product from impacts, falls, dust, moisture, direct sunlight and extreme temperatures.

• Do not immerse the product in water or other liquids.

## Technical specifications


Model: 729 383

Single-use batteries: 1x CR2032/3 V (Li/MnO<sub>2</sub>), watt-hour rating: 0.63 Wh per thermometer (tested as per UN 38.3)


Ambient temperature: +0 to +50 °C

Made exclusively for: Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany


In the course of product improvement, we reserve the right to make technical and optical modifications to the product.




## Inserting / changing batterie




1. Loosen the screw on the battery compartment cover and remove the cover.



2. Remove the used battery from the battery compartment.



3. Slide the new battery under the lip as shown and press it into the battery compartment. Ensure correct polarity (+/-).



4. Replace the battery compartment cover and tighten the screw. The display lights up completely. After approx. 2 seconds, the temperature, time, humidity and comfort level are displayed.

The battery must be replaced if the display shows incorrect values or the display fades. When the battery is replaced, the set time is lost.

## Setting the time

To set the time, proceed as follows:

1. Press and hold the button for approx. 2 seconds until **12 Hr/24 Hr** flashes on the display.
2. Use the or buttons to set the desired display and press the button to save the setting and move to the next display.
3. Now set the hours and minutes one after the other and confirm by pressing .

The set time is shown on the display.

If you press and hold the or button, the hour or minute will advance faster.

## Location

▷ Place or hang the room thermometer in a location where it can be read easily and the temperature is approximately the average room temperature. Do not place it near a radiator, a window, a door or in direct sunlight.

## Selecting the temperature display

You can display the measured room temperature in degrees Celsius (°C) or degrees Fahrenheit (°F).

▷ Briefly press the button to switch between °C and °F.

## Temperature and humidity

The room thermometer displays the **temperature** between 0 °C and 50 °C and the **humidity** between 10% and 95%.

- If the temperature is **below 0 °C**, it displays **LL.L**.
- If the temperature is **above 50 °C**, it displays **HH.H**.
- If the humidity is **below 10%**, it displays **LL.L**.
- If the humidity is **above 95%**, it displays **HH.H**.

The thermometers determine the comfort level based on the temperature and humidity values.

Mounting the room thermometer on the stand supplied



## Comfort level



The humidity is between 40% and 70% and the temperature is between 20 °C and 27 °C (68 °F - 81 °F).



The humidity is below 40% and the temperature is between 20 °C and 27 °C (68 °F - 81 °F).



The humidity is above 70% or the temperature is below 20 °C (68 °F) or higher than 27 °C (81 °F).

## Cleaning

▷ Wipe off the product with a lint-free, slightly damp cloth as necessary.

## Disposal

Dispose of the **packaging** at a recycling point that sorts materials by type. Make use of the local facilities provided for collecting paper, cardboard and lightweight packaging.



**Devices, single-use batteries and rechargeable batteries** marked with this symbol must not be disposed of along with household waste!

You are legally obliged to dispose of old devices separately from household waste. Electronic devices contain hazardous substances and, if stored or disposed of improperly, may cause harm to health and the environment. Information about collection points where old devices can be disposed of free of charge is available from your local authorities. Flat single-use and rechargeable batteries must be handed in at a local authority collection point or returned to a battery retailer. Tape off the contacts of lithium single-use/rechargeable batteries prior to disposal.