


LED Christmas tree candles


en Instructions for use



- If a battery has leaked, avoid all contact with skin, eyes and mucous membranes. If necessary, rinse the affected areas with plenty of clean water and consult a doctor immediately.
- The product is suitable for outdoor use and complies with protection type IPX4. This means it is protected from splashes of water, such as rain. However, you should protect it from heavy rain and streams of water. The product must under no circumstances be operated under water, as this would damage the product. Never immerse it in water or other liquids.
- Protect the product from extreme temperatures. Store the product indoors if the temperature falls below -10 °C, otherwise it may become damaged.
- Due to the extremely long service life of the LEDs, it is not necessary to replace them. They cannot and must not be replaced.
- Do not switch the product on while it is still in the packaging.
- Handle the product with care. Impacts, shocks and falls - even from a low height - may damage the product. For this reason do not attach the candles to thin branches that could break.


Use

Inserting batteries into the remote control



1. Press the side of the battery compartment lid to open the battery compartment.
2. Insert the batteries as illustrated. Ensure that the polarity (+/-) is correct when doing so.
3. Hook the battery compartment lid back into the recesses and fold it shut. You must feel and hear it click into place.

Inserting the battery into the LED candle




1. Turn the plate clockwise towards **Open** and remove it from the candle.
2. Insert the battery as illustrated. Ensure that the polarity (+/-) is correct when doing so.
3. Turn the plate back onto the candle anti-clockwise towards **Close** until tight.


The candle will light up once the plate is securely in place on the battery compartment.

- ▶ If required, switch the candle off using the remote control.

Switching the LED candles on and off



The remote control has a range of approx. 5 m and will detect candles within a radius of approx. 50 cm. Point the remote control in the direction of the candles. Ensure there are no objects blocking the space between the remote control and the candles.



- ▶ Press the **ON** button on the remote control to switch the LED candles on **continuously**. The indicator light will briefly turn red.
- ▶ Press the **OFF** button on the remote control to switch the LED candles off **continuously**. The indicator light will briefly turn red.
- ▶ Press the **TIMER** button on the remote control to switch the LED candles on **in timer mode**. The LED candles will now stay on for **6 hours**. They will then switch off automatically for **18 hours**, then back on again for 6 hours, and so on.
- ▶ Press the **OFF** button on the remote control to deactivate the timer mode and to switch the LED candles off prematurely. The indicator light will briefly turn red.

Technical specifications

Model:	718 141
Remote control	
Single-use batteries:	2x LR03 (AAA)/1.5 V (Zn/MnO ₂)
Range:	approx. 5 metres
Candles	
Single-use batteries:	30x LR03 (AAA)/1.5 V (Zn/MnO ₂)
Bulb:	LED
IP code:	IPX4
Operating time:	approx. 100 hours (with one set of batteries)
Ambient temperature:	-10 °C to +40 °C
Made exclusively for:	Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany

In the course of product improvement, we reserve the right to make technical and optical modifications to the product.

Product number: 718 141

Disposal

The product, its packaging and the supplied batteries have been manufactured from valuable materials that can be recycled. Recycling reduces the amount of refuse and preserves the environment.

Dispose of the **packaging** at a recycling point which sorts materials by type. Make use of the local facilities provided for collecting paper, cardboard and lightweight packaging.



Devices, single-use batteries and rechargeable batteries marked with this symbol must not be disposed of along with household waste!

You are legally obliged to dispose of old devices separately from household waste. Electronic devices contain hazardous substances and, if stored or disposed of improperly, may cause harm to health and the environment. Information about collection points where old devices can be disposed of free of charge is available from your local authorities. Flat single-use and rechargeable batteries must be handed in at a local authority collection point or returned to a battery retailer. Tape off the contacts of lithium single-use/rechargeable batteries prior to disposal.

Safety warnings

Read the safety warnings carefully and only use the product as described in these instructions to avoid accidental injury or damage.

Keep these instructions for future reference. If you give this product to another person, remember to also include these instructions.

The product is only suitable for decoration in private homes and not for lighting whole rooms. The product is designed for indoor and outdoor use. It is designed for private use and is not suitable for commercial purposes.

- This is not a children's toy! Use only under adult supervision. Keep small swallowable parts and packaging materials out of the reach of children. They pose several risks, including the risk of suffocation!

- Swallowing batteries can be fatal. If a battery is swallowed, it can cause severe internal chemical burns and even death within 2 hours. Therefore, keep both new and used batteries and the product out of the reach of infants. If you think that a battery has been swallowed or has got into the body in any other way, seek medical advice immediately.

- Always replace all batteries at the same time. Do not mix old and new batteries, different types or brands of batteries, or batteries with different capacities. Ensure that the polarity (+/-) is correct when inserting the batteries.

- If necessary, clean the battery and device contacts before inserting the batteries. Risk of overheating!

- Single-use batteries must not be charged, taken apart, thrown into fire or short-circuited.

- Protect batteries from excessive heat (radiators, direct sunlight). Remove the batteries immediately from the product when they are flat or if you do not intend to use the product for a longer period of time. This will prevent damage caused by leakage.

Information about the supplied batteries

Manufacturer

New Leader Battery Industry Ltd.
No. 10, Chuangye Road, Industrial Park, Dinghu District, Zhaoqing, PEOPLE'S REPUBLIC OF CHINA
www.newleader.com.hk

Email

sz@newleader.cn

Model

NEW LEADER LR3 AAA 1.5V

Manufacturing date

2026/04

Made in

China



www.tchibo.de/instructions
(Please enter the product number in the box labelled "Bedienungsanleitungssuche" and click on "Suchen".)

