

Read the instructions! Important information – keep for future reference!

Safety warnings

Read the safety warnings carefully and only use the product as described in these instructions to avoid accidental injury or damage. Keep these instructions for future reference. If you give this product to another person, remember to also include these instructions.

Intended use

- The heating pad is designed to warm your abdomen and can be worn under clothing.
- The heating pad is intended for private use. It is not suitable for use in hospitals, therapeutic practices, wellness studios, etc. The heating pad is not a medical device and is not intended to be used as a medical pain relief aid.
- If in doubt, consult your doctor before use.
- The product is exclusively intended for ...
 - ... external use on the body.
 - ... the purpose for which it has been designed and is to be used as outlined in these instructions. Improper use of the product may result in danger to the user!

Danger to children and to people with limited ability to operate devices

- Children aged between 3 and 8 years may use this device only if
 - ... they are continually supervised by their parents or another adult when doing so and
 - ... if the device is kept at the lowest heat setting at minimum temperature.
- This device can be used by children aged 8 and over and by people with reduced physical, sensory or mental capabilities or a lack of experience and/or knowledge, provided they are supervised or have been trained in the safe use of the device and understand the potential dangers. Children must not be allowed to play with the device. Cleaning and maintenance must not be carried out by children without supervision.

Do not use the product ...

- ... on children under 3 years of age, helpless persons, sick persons or persons insensitive to heat or other persons who cannot perceive heat properly. Small children react more sensitively to heat than adults. Taking certain medicines, or suffering from certain diseases, such as diabetes, may lead to disturbances in the sensory perception of temperature. Frail or sick people or those with special needs or disabilities may not be able to call for help if they feel too hot.
- ... if in doubt, or if the user suffers from circulatory problems. Consult your doctor.
- ... on pets or other animals.
- ... in the case of abnormalities or injuries in the area you wish to warm (e.g. in the case of bruising, inflammation, open wounds, skin changes etc.).
- ... after consuming substances which may limit your perceptible abilities (e.g. pain medication, alcohol).

... directly on the eyes, on the face, on or around the genitals, or any other sensitive parts of your body.

... if the device is visibly damaged.

If you feel unwell or have any other complaints while using the product, discontinue use. If necessary, contact a doctor.


Consult your doctor before using the device, particularly if ...

- ... you suffer from a serious condition or have recently undergone an operation.
- ... you wear a pacemaker, implants or anything similar.
- ... you have abnormal blood pressure or are suffering from a high fever.
- ... you are pregnant.
- ... you suffer from pain of unknown origin.
- The heating pad should not be used for longer than 30 minutes. Please note: even low temperatures from 40 °C upwards can lead to skin burns, depending on the duration of use! If noticeable, prolonged reddening is visible after the heat treatment, it may be necessary to consult a doctor. Wait until the skin irritation has subsided before continuing to use the product. Only use the product on the lower heating level (with a piece of fabric underneath if necessary) and only for short periods of time.

Ensure safe use by observing the following instructions:

- Do not insert any pointed objects such as safety pins or other similar objects into the product.
- Do not make any modifications to the product. If the product malfunctions or becomes damaged, have repairs to the product carried out by a specialist workshop.
- Do not leave the product unattended while switched on.

DANGER due to electricity

- The product must only be charged in dry, indoor rooms.
- To charge, only use a suitable USB mains adapter with protection class II (symbol: , approved for household use, with a safety extra-low voltage (SELV) output of 5 V / max. 1 A (see also "Technical specifications") and only the charging cable provided. Do not use or attempt to repair a faulty USB mains adapter. Do not use a faulty charging cable.
- Do not use or charge the product near water. The product must not come into contact with water or other liquids while it is connected to the power supply. Do not submerge the product in water or other liquids while it is charging, as this poses a risk of electric shock.
- Only connect the device to a properly installed power socket with a mains voltage that complies with the technical specifications of the mains adapter used.
- Pull the mains adapter out of the power socket if malfunctions occur while charging, once the device is fully charged, during thunderstorms, and before cleaning the device.

WARNING - risk of fire / explosion

- This product contains a rechargeable lithium polymer battery that, for safety reasons, is firmly built into the device and cannot be removed without destroying the casing. There is a risk of explosion if the battery is replaced incorrectly. It should be replaced only with an identical battery or one of equivalent value. If the rechargeable battery is faulty, consult a specialist workshop.
- Do not charge the product in the vicinity of explosive gases.
- **Warning!** Rechargeable lithium batteries can catch fire or explode ...
 - ... if, during use, charging, storage or transport, they are exposed to strong heat, such as sun, fire, etc. or extremely low air pressure. Only use the product under moderate climatic conditions.
 - ... if taken apart, thrown into fire or short-circuited. Do not place any naked flames, e.g. burning candles, in the vicinity of the product. Candles and other naked flames must be kept away from the product at all times to prevent the spread of fire.
- Do not modify and/or deform/heat/dismantle rechargeable batteries. Do not immerse them in water.
- The device cannot be used during charging and this is also not permitted. Before you charge it, remove it from your body.
- Do not use the product if it or the charging cable provided show visible signs of damage.
- Do not make any modifications to the device. Only have repairs to the product carried out by a specialist workshop. Improper repairs may result in considerable risks to the user.

CAUTION - risk of minor injury and material damage

- Make sure that you do not fall asleep during use. If you become very tired during use, or if you want to use the product for a longer period of time, select the lowest heat setting for precautionary reasons.
- This product is equipped with a thermal switch as protection against overheating. If the switch turns off the product, leave the product to cool to room temperature before switching it back on again.
- Protect the product from dust, moisture, direct sunlight and extreme temperatures.
- Do not sit on the product! Do not place any heavy objects on top of it. This will damage the product.
- Do not use any caustic, aggressive or abrasive products for cleaning.


Charging the battery

To prevent damage to the rechargeable battery, it is only half charged upon delivery. Charge the battery completely before using the product for the first time.



WARNING - risk of fatal electric shock

- To charge, only use a suitable USB mains adapter with protection class II (symbol:), approved for household use, with a safety extra-low voltage (SELV) output of 5 V/ max. 1 A (see also "Technical specifications") and only the charging cable provided.



1. Connect the USB-C charging socket on the product via the charging cable to a suitable USB mains adapter and plug this into a mains socket. The indicator light integrated in the On/Off switch flashes red.

Once the charging indicator light lights up red, the battery is fully charged.

2. Now unplug the mains adapter from the mains socket and disconnect the charging cable.

USB


If the battery is flat, the charging time is approx. 2.5 hours. If the battery is fully charged and the device is set to the highest temperature **H**, operation time is approx. 90 minutes.



- If the indicator light integrated in the On/Off switch flashes red, this indicates that the rechargeable battery is almost drained and must be recharged.
- The device cannot be used during charging and this is also not permitted.
- Charge the battery in an environment between +10 and +40 °C.
- To preserve the battery's full capacity, the battery should be recharged every 3 months even if the device is not being used. The battery will hold its charge for the longest at room temperature. The lower the temperature, the shorter the operating time.

Made exclusively for:
Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany

Use



You can wear the heating pad under your clothes in direct contact with your skin. If this gets too warm, wear it over a piece of fabric, e.g. a vest or T-shirt.

1. Press the clip to open it and attach the heating pad to the top of your trousers or skirt waistband so that the warming surfaces are in contact with your belly.



Press the On/Off switch to switch the device on. The indicator light integrated in the On/Off switch lights up red.

The device always starts on the lower heating level, the indicator light integrated in switch **L** lights up white.

After approx. 30 seconds, the product will have adjusted to the preset heat of approx. 40 °C.

We recommend that you do not initially increase the temperature but wait to see if the temperature is comfortable over a reasonable time (up to 90 minutes).

If during that time it was not warm enough for you, you can set the higher heating level **H** next time.

2. To set the higher heating level, press the **H** button. The indicator light integrated in switch **H** lights up red.

After a few seconds, the product will have adjusted to the preset heat of approx. 45 °C.



If it becomes uncomfortable or even painful, switch off the device immediately and remove it (see also "Safety warnings").



After approx. 15 minutes, the device will switch off automatically.

Care

NOTICE - material damage

- Do not wash!
- Do not immerse the device in water or other liquids.
- Do not use any caustic, aggressive or abrasive products for cleaning.

- ▷ Disconnect the device from the power supply before cleaning it.
- ▷ Wipe the control unit only with a dry, lint-free cloth.
- ▷ If necessary, wipe the heating pad with a damp cloth on the inside and outside.
If necessary, use an alcohol-based cleaning cloth (never use benzene!).

Disposal

The product, its packaging and the built-in rechargeable battery have been manufactured from valuable materials that can be recycled. Recycling reduces the amount of refuse and preserves the environment. Dispose of the **packaging** at a recycling point that sorts materials by type. Make use of the local facilities provided for collecting paper, cardboard and lightweight packaging.



Devices, single-use batteries and rechargeable batteries marked with this symbol must not be disposed of along with household waste!

You are legally obliged to dispose of old devices separately from household waste. Electronic devices contain hazardous substances and, if stored or disposed of improperly, may cause harm to health and the environment. Information about collection points where old devices can be disposed of free of charge is available from your local authorities. Flat single-use and rechargeable batteries must be handed in at a local authority collection point or returned to a battery retailer. Tape off the contacts of lithium single-use/rechargeable batteries prior to disposal.

Warning! This device contains a battery that, for safety reasons, is firmly built into the device. It cannot be removed without destroying the casing. Improper disassembly leads to safety hazards.

For this reason, take the device intact to a collection point where the device and battery will be disposed of properly.

Technical specifications

Model:	718 337
Rechargeable battery:	Lithium polymer 3.7 V 1000 mAh <small>(the symbol indicates direct current)</small>
	Watt-hour rating: 3.7 Wh (tested as per UN 38.3)
Charging time:	approx. 2.5 hours
Max. operation time:	approx. 90 minutes (at heat level H)
Temperature:	Level L = approx. 40 °C Level H = approx. 45 °C
Input power:	DC 5 V / 1.0 A (SELV)
Rated power:	3.7 W
Power consumption when switched off:	0.3 W
Protection class:	III
Mains adapter (not included):	Input: AC 100-240 V 50/60 Hz Output: DC 5 V 1.0 A
Ambient temperature:	+10 to +40 °C

Information about the inserted rechargeable battery

Manufacturer:	Guangdong Beron Energy Technology Co., Ltd., Building 1, No.190 Hengli Chengxiang Road, Hengli Town, Dongguan City, Guangdong Province, PR China
Email:	bis06@beronenergy.com
Model:	603048-3.7V-1000mAh
Manufacturing Date:	2025/07
Made in:	China

Product number: 718 337



www.tchibo.de/instructions